


TROUBLESHOOTING EFI ELECTRONIC CIRCUIT WITH VOLT OHMMETER






HINT: The following troubleshooting procedures are designed for inspection of each separate system, therefore, the procedure may vary somewhat. However, troubleshooting should be performed while referring to the inspection methods described in this manual.






Before beginning inspection, it is best to first make a simple check of the fuses, fusible links and the condition of the connectors.

The following troubleshooting procedures are based on the supposition that the trouble lies in either a short or open circuit in a component outside the computer or a short circuit within the computer. If engine trouble occurs even though proper operating voltage is detected in the computer connector, then it can be assumed the computer is faulty and should be replaced.

LOCATION OF FUSES AND FUSIBLE LINKS
















No.	Terminal	Trouble	Condition	STD voltage
3	IDL - E2	No voltage	Throttle valve open	10 - 14 V
	VTA - E2		Throttle valve fully closed	0.1 - 1.0 V
	VCC - E2		Throttle valve fully open	4 - 5 V
			—	4 - 6 V

FI0485




• IDL - E2







• VTA - E2






• VC - E2



No.	Terminal	Trouble	Condition		STD Voltage
4	+ B1 – E2	No voltage	Ignition switch ON	—	10 – 14 V
	VC – E2			—	6 – 10 V
	Measuring plate fully closed			2 – 5.5 V	
	Measuring plate fully open			6 – 9 V	
	VS – E2	Idling	—	2 – 8 V	



FI2581



① There is no specified voltage at ECU terminals VC or VS and E2. (**IG SW ON**)

② Check that there is voltage between ECU terminal +B (+B1) and body ground. (**IG SW ON**)

OK

NO

Refer to +B - E1 trouble section (No. 1) (See page FI-114)

Check wiring between ECU terminal E1 and body ground.

OK

BAD

③ Check air flow meter. (See page FI-147)

Repair or replace.

BAD

OK

Replace air flow meter.





Check wiring between ECU and air flow meter.

OK

BAD

Try another ECU.

Repair or replace.



(1) There is no voltage between ECU terminals No. 10 and/or No. 20 and E01 and/or E02. **(IG SW ON)**

(2) Check that there is voltage between ECU terminal No. 10 and/or No. 20 and body ground.

NO

OK

Check wiring between ECU terminal E01 and/or E02 and body ground.

OK

BAD

Try another ECU.

Repair or replace.

Check fuse, fusible link and ignition switch.

BAD

Repair or replace.

OK

(3) Check resistance of magnetic coil in each injector.
STD resistance: Approx. 13.8Ω

OK

BAD


Replace injector.

Check wiring between ECU terminal No. 10 and/or No. 20 and battery.


BAD

Repair or replace.


No.	Terminal	Trouble	Condition	STD voltage
6	W - E1	No voltage	No trouble ("CHECK ENGINE" warning light off) and engine running.	10 - 14 V




FI0728



FI4324



FI4325



FI4315

① There is no voltage between ECU terminals W and E1. (idling)

② Check that there is voltage between ECU terminal W and body ground.

NO

OK

③ Check wiring between ECU terminal E1 and body ground.

OK

BAD

Try another ECU.

Repair or replace.

Check GAUGE fuse and check engine warning light.

OK

BAD



Repair or replace.

Fuse blows again

Check wiring between ECU terminal W and fuse.

BAD

Repair or replace.




① There is no specified voltage between ECU terminals THA and E2. (**IG SW ON**)

② Check that there is voltage between ECU terminal + B (+B1) and body ground. (**IG SW ON**)

OK

NO

Refer to + B - E1 trouble section (No 1). (See page FI-114)



Check wiring between ECU terminal E1 and body ground.

OK

BAD

③ Check air flow meter. (See page FI-117)

BAD

OK

Replace air flow meter.

Repair or replace.


Check wiring between ECU and air temp. sensor.



OK

BAD

Try another ECU.

Repair or replace.





① There is no voltage between ECU terminals THW and E2. (IG SW ON)

② Check that there is voltage between ECU terminal +B (+B1) and body ground. (IG SW ON)

OK

NO

Refer to +B - E1 trouble section (No. 1). (See page FI-114)

Check wiring between ECU terminal E1 and body ground.

OK

BAD

③ Check water temp. sensor. (See page FI-159)

BAD

OK

Replace water temp. sensor.

Check wiring between ECU and water temp. sensor.



Repair or replace.






OK





BAD

Try another ECU.

Repair or replace.







① There is no voltage between ECU terminals IGT and E1. (idling)

② Check that there is voltage between ECU terminal IGT and body ground. (idling)

OK
(3) Check wiring between ECU terminal E1 and Check ground.

Refer to + B - E1 trouble section (No. 1). (See page FI-114)

BAD

Repair or replace.

Check wiring between ECU and distributor.

BAD

Repair or replace.

Check distributor.

BAD

Replace.

Check wiring between ECU and igniter.

BAD






Repair or replace.

Check igniter. (See page IG-8)

BAD




Repair or replace.

Try another ECU .




Wiring diagram for the Oxygen Sensor Heater. The diagram shows a power source +B connected to the Oxygen Sensor Heater. The heater is represented by a resistor symbol. The Oxygen Sensor is connected to the heater. The heater is connected to the Check Connector. The Check Connector has terminals VF1, E1, TE1, OX1, HT, and OX+. The OX+ terminal is connected to ground.


The diagram illustrates the electrical connections between the ECU and various sensors. On the left, a +B battery terminal is connected to the Main Oxygen Sensor. The Main Oxygen Sensor is connected to the ECU terminals VF, E1, and TE1. The Sub-oxygen Sensor is connected to the ECU terminals OX1, HT, OX2, and E1. The Oxygen Heater is connected to the ECU terminals OX1 and HT. The Check Connector is connected to the ECU terminals VF1, E1, and TE1. The ECU is represented by a large box on the right with terminals labeled VF, E1, TE1, VF1, E1, TE1, OX1, HT, OX2, and E1. The sensors are represented by boxes on the left with internal wiring symbols. The battery is represented by a +B terminal and a ground symbol.



California




FI128B0



①

① There is no voltage between ECU terminals THG and E2.
(IG SW ON)



②

② Check that there is voltage between ECU terminal +B (+B1)
and body ground. (IG SW ON)

OK

NO

Refer to +B - E1 trouble section (No. 1).
(See page FI-114)

Check wiring between ECU terminal E1 and body ground.

OK

BAD

Check EGR system.

BAD

Repair or replace.

OK

③ Check EGR gas temp. sensor. (See page FI-160)

BAD

OK

Replace EGR gas
temp. sensor.


Check wiring between ECU and
EGR gas temp. sensor.

OK

BAD

Try another ECU.

Repair or replace.



FI1501