TROUBLESHOOTING TROUBLESHOOTING

HINTS

- Engine troubles are usually not caused by the EFI system. When troubleshooting, always first check the condition of the other systems.
 - (a) Electronic source
 - Battery
 - Fusible links
 - Fuses
 - (b) Body ground
 - (c) Fuel supply
 - Fuel leakage
 - Fuel filter
 - Fuel pump
 - (d) Ignition system
 - Spark plugs
 - High-tension cords
 - Distributor
 - Igniter and ignition coil
 - (e) Air induction system
 - Vacuum leaks
 - (f) Emission control system
 - PCV system
 - EGR system
 - (g) Others
 - Ignition timing (ESA system)
 - Idle speed
 - etc.
- 2. The most frequent cause of problems is simply a bad contact in wiring connectors. Always make sure that connections are secure.

When inspecting the connector, pay particular attention to the following points:

- (a) Check to see that the terminals are not bent.
- (b) Check to see that the connector is pushed in completely and locked.
- (c) Check to see that there is no signal change when the connector is slightly tapped or wiggled.
- 3. Sufficiently troubleshoot for other causes before replacing the ECU. The ECU is of high quality and is expensive.







4. Use a volt/ohmmeter with high impedance (10 k Ω /V minimum) for troubleshooting of the electrical circuit. (See page FI-113)

TROUBLESHOOTING PROCEDURES

SYMPTOM – DIFFICULT TO START OR NO START (ENGINE WILL NOT CRANK OR CRANKS SLOWLY)



SYMPTOM – DIFFICULT TO START OR NO START (CRANKS OK)



\downarrow OK $\,$ Continued from Page FI–94 $\,$

	-	
CHECK IGNITION TIMING	NO	Ignition timing – Adjust
1. Connect terminals TE1 and E1 of the check		(See page IG-19)
engine connector.		
2. Check ignition timing. STD: 10° BTDC @ idling		
(w/ TE1 and E1 connected)		
† OK		
CHECK FUEL SUPPLY TO INJECTOR	BAD	1. Fuel line – Leakage – Deformation
1. Fuel in tank		2. Fuse
2. Fuel pressure in fuel line		3. Circuit opening relay (See page FI-157)
check connector.		4. Fuel pump (See page FI–129)
(2) Fuel pressure at fuel return hose can		5. Fuel filter
be felt. (See page EL-130)		6. Fuel pressure regulator (See page FI-138)
(See page 11–150)	J	
		Air flow meter (See page EI-147)
FLOW METER	BAD	
Check continuity between terminals FC and E	1	
while measuring plate of air flow meter is open	ŀ	
ок		1 Sport pluge (See page IC 10)
CHECK SPARK PLUGS	NO	2. Compression pressure (See page EM–29)
Plug gap: 0.8 mm (0.031 in.)	140	Limit: 10.0 kg/cm ² 0 42 psi, 981 kPa)
HINT:		at 250 rpm
Check compression pressure and valve		STD: IN 0.15 – 0.25 mm
clearance if necessary.		(0.006 – 0.010 in.)
		EX 0.20 – 0.30 mm
		(0.000 – 0.012 m.)
		1. Injectors – Shorted or leaking
		2. Injector wiring(s)
	Pluas	(See page FI-135)
	WET	4. Start injector time switch
		(See page FI-158)
I OK		
CHECK AUXILIARY AIR VALVE	-	1. Auxiliary air valve
(See page FI-154)	BAD	2. Water noses 3. Air hoses
Lau		
		Intake valve – Deposit
	BAD	
	BAD	1. Wiring connection
(See page EI-111)		(1) Fusible links
		(2) Fuses
		(3) EFI main relay 3 Air flow meter
		4. Water temp. sensor
		5. Intake air temp. sensor
		6. Injection signal circuit
		(2) ECU

SYMPTOM – ENGINE OFTEN STALLS





SYMPTOM – ENGINE SOMETIMES STALLS

CHECK DIAGNOSIS SYSTEM Check for output of diagnostic code. (See page FI–105)	Malfunction code(s)	Diagnostic code(s) (See pages FI–108 and FI–109)
Normal code		
CHECK AIR FLOW METER (See page FI–147)	BAD	Air flow meter
ок		
CHECK WIRING CONNECTORS AND RELAYS Check that there is a signal change when the connector or relay is slightly tapped or wiggled.	BAD	 Connectors EFI main relay (See page FI–156) Circuit opening relay (See page FI–157)

SYMPTOM – ROUGH IDLING AND/OR MISSING

CHECK DIAGNOSIS SYSTEM	1	Diagnostic code(s)
Check for output of diagnostic code.	Malfunction	(See pages FI–108 and FI–109)
(See page FI-105)	code(s)	
Normal code	-	
CHECK FOR VACUUM LEAKS IN AIR INTAKE LINE	BAD	 Oil dipstick Hose connections PCV hose EGR system – EGR valve stays open
ок		
CHECK AIR FILTER ELEMENT	BAD	Element – Clean or replace
ок	-	
CHECK IDLE SPEED	NO	Idle speed – Adjust
STD: 800 rpm		(See page MA-19)
ок		
 CHECK IGNITION TIMING 1. Connect terminals TE1 and E1 of the check connector. 2. Check ignition timing. STD: 10° BTDC @ idling (w/ TE1 – E1 connected) 	NO	Ignition timing – Adjust (See page IG–19)
ок		
CHECK SPARK PLUGS Plug gap: 0.8 mm t0.031 in.) HINT: Check compression pressure and valve clearance if necessary.	NO	 Spark plugs (See page IG-10) Compression pressure (See page EM-29 Minimum: 10.0 kg/cm² (142 psi, 981 kPa) at 250 rpm Valve clearance (Cold) (See page EM-22 Standard: IN 0.15 - 0.25 mm (0.006 - 0.010 in.) EX 0.20 - 0.30 mm (0.008 - 0.012 in.)
ок]	
CHECK COLD START INJECTOR	BAD	1. Cold start injector (Leakage)
(See page FI-135)		2. Start injector time switch. (See page FI-158)
OK CONTINUED ON PAGE FI-S	- 99	



SYMPTOM – HIGH ENGINE IDLE SPEED (NO DROP) CHECK ACCELERATOR LINKAGE BAD Linkage - Stuck dash pot system OK CHECK AUXILIARY AIR VALVE 1. Auxiliary air valve – Always open BAD (See page FI-154) 2. Water hoses 3. Air hoses OK CHECK AIR CONDITIONER AND BAD Air valve for air conditioner – Leakage VSV for air conditioner - Leakage POWER STEERING IDLE–UP CIRCUIT OK CHECK DIAGNOSIS SYSTEM Malfunction Diagnostic code(s) Check for output of diagnosis code. (See pages FI-108 and FI-109) code(s) (See page FI-105) Normal code CHECK THROTTLE POSITION SENSOR BAD Throttle body (See page FI-149) OK CHECK FUEL PRESSURE BAD Fuel pressure regulator – High pressure (See page FI-130) OK CHECK COLD START INJECTOR Cold start injector - Leakage BAD (See page FI-135) OK CHECK INJECTORS (See page FI-139) BAD Injectors - Leakage, Injection quality OK CHECK EFI ELECTRONIC CIRCUIT BAD 1. Wiring connection 2. Power to ECU **USING VOLT/OHMMETER** (1) Fusible links (See page FI-113) (2) Fuses (3) EFI main relay 3. Air flow meter 4. Water temp. sensor 5. Intake air temp. sensor 6. Injection signal circuit (1) Injector wiring (2) EĊU

SYMPTOM – ENGINE BACKFIRES–Lean Fuel Mixture



SYMPTOM – MUFFLER EXPLOSION (AFTER FIRE) –Rich Fuel Mixture–Misfire



SYMPTOM – ENGINE HESITATES AND/OR POOR ACCELERATION

CHECK CLUTCH OR BRAKE	BAD	1. Clutch – Slips 2. Brakes – Drag
OK CHECK FOR VACUUM LEAKS IN AIR INTAKE LINE	BAD	 Oil dipstick Hose connections PCV hose EGR system – EGR valve stays open
ок		
CHECK AIR FILTER ELEMENT	BAD	Element – Clean or replace
ок		
CHECK DIAGNOSIS SYSTEM Check for output of diagnostic code. (See page FI–102)	Malfunction code(s)	Diagnosis code(s) (See pages FI–108 and FI–109)
Normal code		
 CHECK IGNITION SPARK 1. Unplug connectors of injector and start injector time switch. 2. Check by holding spark plug 8 – 10 mm (0. 31 – 0.39 in.) away from engine block while cranking engine. A strong spark should be noted. 	BAD	 High-tension cords Distributor Ignition coil, Igniter
ок		
 CHECK IGNITION TIMING 1. Connect terminals TE1 and E1 of the check connector. 2. Check ignition timing. STD: 10° BTDC @ idling (w/ TE1 – E1 connected) 	NO	Ignition timing – Adjust (See page IG–19)
ок		
CHECK FUEL PRESSURE (See page FI–130)	BAD	 Fuel pump (See page FI–129) Fuel filter Fuel pressure regulator (See page FI–138)
ок		
CHECK INJECTORS	BAD	Injection condition

