INSTALLATION

Installation is in the reverse order of removal (See page IG-7).

IG00X-04