

## INSTALLATION

### 1. INSTALL UPPER SUSPENSION ARM TO BODY

Torque: 59 N·m (600 kgf·cm, 44 ft·lbf)

HINT:

After stabilizing the suspension, torque the bolt.

### 2. INSTALL FRONT SHOCK ABSORBER (See page [SA-27](#) )

### 3. INSTALL FRONT WHEEL

Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)

### 4. CHECK FRONT WHEEL ALIGNMENT (See page [SA-5](#) )

### 5. CHECK ABS SPEED SENSOR SIGNAL

w/ VSC (See page [DI-507](#) )

w/o VSC (See page [DI-437](#) )