




INSTALLATION

1. INSTALL COOLING FAN

- (a) Install the cooling fan with the 6 bolts.
Torque: 5.0 N·m (50 kgf·cm, 44 in·lbf)
 - (b) Connect the upper radiator hose to the radiator.
 - (c) Connect the ECM outlet duct to the ECM box.
 - (d) Connect the wire for cooling fan to clamp on the cooling fan.
 - (e) Connect the 2 cooling fan connectors.
 - (f) Connect the radiator reservoir hose to the radiator.
- ### 2. INSTALL AIR CLEANER AND MAF METER ASSEMBLY
- ### 3. INSTALL AIR CLEANER INLET
- ### 4. FILL WITH ENGINE COOLANT
- ### 5. START ENGINE AND CHECK FOR COOLANT LEAKS