

TORQUE SPECIFICATION

Part tightened	N·m	kgf·cm	ft·lbf
Extension housing x Transmission case	34	345	25
Transmission mounting bracket x Extension housing	12	120	9
Engine rear support member x Frame	25	260	19
Engine rear support member x Transmission mounting bracket	12	120	9
Vehicle speed sensor set bolt	5.4	55	48 in.·lbf
O/D direct clutch speed sensor set bolt	5.4	55	48 in.·lbf
AFT temperature sensor connector set bolt	5.4	55	48 in.·lbf
Drain plug	20	205	15
Shift solenoid valve SLU and SLT set bolt	6.4	65	56 in.·lbf
Shift solenoid valve SLN and No. 4 set bolt	10	100	7
Shift solenoid valve clamp set bolt	6.4	65	56 in.·lbf
Shift solenoid valve No. 1 and No. 3	6.4	65	56
Shift solenoid valve No. 2	10	100	7
Shift control rod set nut	13	130	9
Valve body x Transmission case	10	100	7
Oil pan x Transmission case	7.4	75	65 in.·lbf
Oil strainer x Valve body	10	100	7
Parking lock pawl bracket x Transmission case	7.4	75	65 in.·lbf
Control shaft lever set nut	13	130	9
Shift lever guide housing assembly x Shift lever plate	4.9	50	43 in.·lbf
Floor shift lever assembly set bolt	8.3	85	73 in.·lbf
Oil cooler pipe clamp bolt	5.4	55	48 in.·lbf
Oil cooler pipe union nut	44	450	33
Transmission x Engine	14 mm head	37	27
	17 mm head	72	53
Starter x Transmission	37	380	27
Exhaust pipe assembly x Exhaust manifold	62	632	46
Exhaust manifold with TWC x Engine	39	400	29
Pipe support bracket x Transmission	43	438	32
Torque converter clutch x Drive plate	48	490	35
Propeller shaft x Differential	74	750	54
Propeller shaft x Body	49	500	36
Drive plate x Crankshaft	83	850	61