


## REAR DIFFERENTIAL SIDE GEAR SHAFT OIL SEAL

A lip with a spiral pattern is adopted for the rear differential side gear shaft oil seals.

- A left-hand spiral is used for the lip on the left side seal, and a right-hand spiral is used for the lip of the right side seal.
- The spiral pattern leads oil toward the inside of the differential when the drive shaft rotates, ensuring sealing performance.



08D0CH05C

### Service Tip

The right and left rear differential side gear shaft oil seals are different. Confirm the direction of the spiral pattern before installation. For details, see the LEXUS IS F Repair Manual (Pub. No. RM08E0E).