


VDIM

VDIM (Vehicle Dynamics Integrated Management) integrally controls engine output and braking in coordination with steering control to ensure vehicle running, cornering and stopping performance for active safety.

- In the past, ABS, Brake Assist, TRC, and VSC acted independently, with control starting at the limit of vehicle running, cornering and stopping performance.
- VDIM, however, begins control earlier in order to help ensure that the vehicle does not exceed its behavioral limits.



0151CH09C