A3

Engine Room
Main Wire

D3

D2

Instrument
Panel Wire

Roof Wire

A2

Front Door
Wire LH

Engine Room
Main Wire

D4

Front Door
Wire RH

D1

No. 1 Floor Wire

No. 2 Floor Wire   No. 2 Floor Wire   No. 1 Floor Wire   Instrument
Panel Wire Assembly