

F RELAY LOCATIONS

[Instrument Panel] (RHD)

- * 1: Refer to the Service Bulletin for the installation position of the parts.
- * 2: w/ ID Code Box
- * 3: w/ Transponder Key ECU Assembly

