







D30(A)
Passenger Side Squib Circuit
(Instrument Panel Passenger Airbag without Door Assembly)



D62
Lower No. 1 Instrument Panel
Airbag Assembly



D27(A), G1(B), H17(C)
Airbag ECU Assembly




A58
Front Airbag Sensor LH


A51
Front Airbag Sensor RH


H22
Front Seat Outer Belt
Assembly LH


- * 1 : w/ Dual Airbag
- * 2 : w/o Dual Airbag
- * 3 : w/ Airbag Cut Off Switch Cylinder Sub-Assembly
- * 4 : w/ Lower No. 1 Instrument Panel Airbag Assembly



* 5 : w/ Passenger Airbag Cut-Off Indicator









A 17
Gray

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

A 33
White

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	17
18	19	20	21	22	23			24	25
26	27			28	29			30	31



D 7
White

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

D 10
White



16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

D 18
White

1	2	3	4	5	6	7
8	9	10	11	12	13	14

D 27
White

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30



D 43
Gray





1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

D 46
Black

1	2	3	4	5	6
7	8	9	10	11	12

D 47
Black

1	2	3	4	5	6
7	8	9	10	11	12



G 1
White

1	2	3	4	5
6	7	8	9	10
11	12	13	14	15

