



INSTALLATION

1. INSTALL TOE CONTROL LINK

- (a) Install the toe control link, toe control link piece to the rear suspension member with the cam bolt, cam plate and nut.

Torque: 49 N·m (500 kgf·cm, 36 ft·lbf)

HINT:

After stabilizing the suspension arm, align the matchmarks on the cam plate and rear suspension member, and torque the nut.

- (b) Connect the toe control link to the axle carrier with a new nut.

Torque: 49 N·m (500 kgf·cm, 36 ft·lbf)

2. CONNECT ABS SPEED SENSOR WIRE HARNESS TO TOE CONTROL LINK

Torque: 5.0 N·m (51 kgf·cm, 44 in.-lbf)

3. INSTALL REAR FENDER APRON SEAL

4. INSTALL REAR WHEEL

Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)

5. CHECK REAR WHEEL ALIGNMENT (See page [SA-9](#))